

## MF14 / Drawing atlas

# Dimensions & installation

Independent views grouped by motor installation.

Drawing unit unverified; original dimension labels are retained.

Reference dimensions; confirm mounting and stroke for your configuration.

Use labelled dimensions; do not scale the drawings.

### C outside

3 views | pp. 2-4

### D inside

5 views | pp. 5-7

### L left

5 views | pp. 8-10

### R right

5 views | pp. 11-13

### B lower


4 views | pp. 14-16

Product specifications and selection guidance are supplied separately.

For configuration-specific dimensions or actual CAD files, contact HTROBOT.

# MF14 / C outside


View 1




## MF14 / C outside

### Section Flange

### B向视图




### 电机法兰视图




# MF14 / C outside

## Installation overview




# MF14 / D inside


View 1




View 2



View 3





电机法兰视图



## MF14 / D inside


### Section Flange

### B向视图




# MF14 / D inside

## Installation overview




# MF14 / L left


View 1



View 2




View 3




**MF14 / L left**

## Section Flange

### B向视图




## 电机法兰视图




**MF14 / L left**

## Installation overview




# MF14 / R right


View 1



View 2




View 3




## MF14 / R right

## Section Flange

### B向视图




## 电机法兰视图




# MF14 / R right

## Installation overview




# MF14 / B lower

View 1




View 2




# MF14 / B lower

## Section Flange

### B向视图



### 电机法兰视图



# MF14 / B lower

## Installation overview

