




SL150 dimensions

Dimensions and installation views. Units are the labels printed on each view.

These drawings do not select a stroke. Confirm mounting against the configuration you order.

Drawings: 2 views. end 1040, end 1042

SL150 · Drawings · end 1040



SL150 · Drawings · end 1042

