



TML220 dimensions

Dimensions and installation views. Units are the labels printed on each view.

These drawings do not select a stroke. Confirm mounting against the configuration you order.

Drawings: 1 views. top with cover;
dimensional view only

TML220 · Drawings · top with cover;
dimensional view only

